002
K :392x542mm :130x180/mm :50/mm : : 2/F/1302726-English-manual.cdr : 13.09.27 :

D. Specifications

Size (1pc): 62cm × 62cm ×160cm
Appliance Gross weight: 3.31kg
Rated Voltage: 120V
Rated Frequency: 60Hz
Rated Power: 900W
Rated clothes to be dried 15kg
Clothes drying period: 0-180 min

E. Parts and Components Table

Item	Quantity
Motor unit	1
Water proof plate	1
Upper supporting tube	1
Lower supporting tube	1
Connector	1
Standing feet	3
Cover	1
User manual	1
S-Hooks	10
Carry bag	1

F. Installation



Insert 3 pieces of standing feet into
corresponding holes on the bottom of the motor unit.

DRYER SHOULD NOT BE MOUNTED
ON SLOPED SURFACE

Fit rack onto the upper supporting tube

Fit the water proof plate onto
the lower supporting tube, then
attach upper tube to the lower
supporting tube using connector



Tighten connector to both poles
and tighten lower pole to heating outlet

Using S Hooks, hang equipment and clothes
to top rack.
Place cover over top rack and close
tightly with the zippers

G. Disassembly

To disassemble this machine, just follow the above installation steps in reverse.

MADE IN CHINA

DISTRIBUTED BY
GLOBAL PREMIUMS
MONTREAL , CANADA

WWW.ROCKETSPORTDRYER.COM
INFO@ ROCKETSPORTDRYER.COM

www.facebook.com/RocketSportDryer

USER MANUAL

Please read this manual carefully before using

WARRANTY CARD

WARRANTY:VALID 1 YEAR ON MOTOR

Product name: ROCKET SPORT DRYER
Clothes dryer Model No.: MZX-Y90
Name :
Address:
Postal code:
Tel #:
Dealer Name:
Address of Dealer:
Tel # of Dealer:
Purchase Date:

RETURN TO:

ROCKET SPORT DRYER
3551 ST CHARLES #144
KIRKLAND, QUEBEC , CANADA
H9H 3C4

H. Operating Instructions

1.Insert the power plug into grounded power socket.
2.Rotate the switch clockwise and set automatic time.
3.Regular drying time is 1 hour.
4. NOTE: Dryer Timer May Vary up to 20%



I. Trouble Shooting

Number	Problem	Possible cause
1	Drying time too long (>180min)	1.Equipment or clothes unevenly placed on racks. 2.Cover not closed properly and air is leaking.
2	Machine suddenly stopped.	1.Air entry or outlet blocked with equipment or clothes. 2.Exceeded set time.

J. Structure



Contents

A. Caution
B. Features
C. Working principle
D. Specifications
E. Parts and Components Table
F. Installation
G. Disassembly
H. Operating Instructions
I. Trouble Shooting
J. Structure

A. Caution

1. Whenever this machine is being used, keep it at least 1.5 meters away from motor or fire source. Clean it with damp cloth. Never submerge motor in water.
2. Make sure the power supply socket is grounded.
3. Never touch the metal parts on the air-outlet. Allow sufficient time to cool before touching metal components (30-60minutes)
4. Keep children away from this machine when it is working.
5. Equipment and clothes to be dried should be able to endure 165°F (74°C) temperature. Rack can support maximum of 15kgs
6. Air-entry and outlet should be free from obstruction.

B. Features

1.Positive Temperature Co-Efficient (PTC) heating-element, different from traditional heating method, to ensure maximum safety. Multi heating-protection, electricity leak prevention and auto-shut off devices are built in.
2.Multi function: equipment and clothes dryer, room warmer and clothes rack.
3.Eco-friendly: save energy compared with traditional appliances.
4.High efficiency: 1 hour to dry equipment and clothes.
5.Convenient: small, light, easy assembly/disassembly and convenient for travel, tournaments and camps.

C. Working principle

PTC heating element is safe, energy efficient, durable and will not corrode.
This appliance adopts the working principle of
* Fan to form a positive air pressure inside the cover.
* Heated Air by the PTC heating element to reduce smell and kill bacteria on equipment and clothes.